
# Front Panel Removal and Installation

## Safety Notice

Disconnect power before removing the front panel.

### Remove Front Panel




Gently pry from the bottom gap and detach the panel.

### Install Front Panel




Align the panel and press firmly until it clicks into place.

**Note:**


If the device is powered on, touch control may take up to 1 minute to respond after reinstalling the front panel. For immediate response, power cycle the device.


# Wiring Diagram

## Important:


- A neutral wire is required for all switch models.
- Turn off power at the circuit breaker before installation.

### 1 Gang Switch




### 2 Gang Switch








# Installation Instructions

## ⚠ Turn off power at the circuit breaker before installation.


1. Use a compatible mounting box as shown below. Figures 1 and 2 show EU mounting boxes. Figure 3 shows a US mounting box.




2. Turn off power and connect the wires according to the wiring diagram.
Tool Required:
Flat-head screwdriver ⊖




3. Secure the switch into the wall box and tighten screws.




4. Install the front panel and restore power.

